




## UTICA® Breezeway

### -Instructions-


Please read this manual carefully before use, strictly follow the instructions for correct use, and properly store the manual for future use

### Product Parameters



### Product Parameters

Materials: ABS/PP, PC electronic components/metal hardware  
Net Weight: 186G  
Battery Capacity: 3000mAh  
Battery Voltage: 3.7V  
Maximum Output Power: 9W  
Product Dimensions: 52.3\*54.3\*165.8mm  
Product Execution Standard: GB4706.27-2008  
Inspection: Qualified Product



### Functional Operations

#### Fan Working Modes

Press Button 1 briefly for the first time, and the fan will enter the first gear mode. The display screen will show "1". Press Button 1 briefly for the second time, and the fan will enter the second gear mode. The display screen will show "25". Press Button 1 briefly for the third time, and the fan will enter the third gear mode. The display screen will show "50". Press Button 1 briefly for the fourth time, and the fan will enter the fourth gear mode. The display screen will show "75". Press Button 1 briefly for the fifth time, and the fan will enter the fifth gear mode. The display screen will show "100". The above operations are cyclic.

#### Stepless Speed Regulation Mode

When the fan is turned on:  
Press Button 1 for a long time, and the air volume will increase until it reaches the 100th gear.  
Press Button 2 for a long time, and the air volume will decrease until it reaches the 1st gear.

#### Cooling Mode Operation

The Cooling mode can be turned on at any gear of the fan. Press Button 2 briefly to turn on the Cooling mode, and press Button 2 briefly again to turn off the Cooling mode.

#### Charging Mode

When charging, the battery level on the display screen will flash. When the battery is fully charged, the display screen will show "100" and remain constantly lit.

### Display Screen Functions

During the charging process, the battery level on the display screen flashes. When fully charged, the display shows "100" and stays constantly lit.

When the fan is operating, the display screen shows the working gear.

### Duration of Use After a Full Charge

It takes approximately 4 hours to fully charge this device.

Fan Usage Duration

IFirst Gear: Approximately 9 hours

ISecond Gear: Approximately 6 hours

IThird Gear: Approximately 4 hours

IFourth Gear: Approximately 3 hours

IFifth Gear: Approximately 2.5 hours

IUse with Fan and Refrigeration Function Enabled:  
Approximately 1 to 2 hours.

### Product Maintenance

After purchasing the product, please charge it for more than 2 hours before using it.

Charge the product once every three months when it is in storage to prevent battery damage.

Do not allow children aged 0 to 10 to use this product alone.

### Product Configuration

1 foldable high-speed cooling fan  
1 USB data cable  
1 instruction manual